


# BIG PINK hanging lamp





Please note the information contained in the instruction and save this manual.

## Technical data


Use only compact fluorescent (energy-saving) bulbs. **Never use traditional hot bulbs.**

This lamp is suitable only for **indoor lighting**, and not for areas in which moisture-proofing is required. Never use outside. The inflatable lampshade is made of calendered PVC, high frequency electrically welded.




## Setting-up


1. Inflate the PVC lampshade using pump of any kind (car/bicycle/toy pump) or air compressor. Inflate in room temperature. Don't inflate it to much – there must be delicate folding (“wrinkles”) on the edges. **Don't inflate by mouth** (the steam could be visible inside the shade). Close the valve tight. Put the transparent plastic holder with socket into the shade, loosen the white plastic ring at the socket and turn around one half of the plastic holder like on the picture. Small holes on the holder are to mark the right position and should overlap. Fix the white ring. **Attention** – always turn back the holder before removing it from the lampshade.



2. Check if the holder is placed in the right position, like on the picture. You can shorten the length of the hanging line if necessary. To release the line turn round small metal cap and take it down; press threaded part and pull the line. Cut the line, regulate the loop and fix it in new position with the small screws. After releasing the line you can also move the metal cover up and down.



3. How to shorten the length of the hanging line and to connect the lamp to the electricity.



Remember: Always shut off power of the circuit before starting installation work! Always choose screws and plugs that are specially suited to the material in your ceiling.



**Inflate the PVC shade in a room temperature. After storage in a cold room wait until the items will warm up prior to pumping.** Under the influence of changes in ambient temperature the volume of inflatable shade may vary. You can add a little more air into the lampshade after few days, when the material will stretch out.

### Conservation and cleaning

PVC lampshade should be cleaned with soft wet cloth, using mild detergents. Can be also washed with soap and shower after unplugging all electric installation and hard-plastic construction. Always turn back the holder before removing it from the shade. After washing dry the shade with soft cloth. Put the holder and socket inside the shade when it's dry.

For serious, oily stains you can locally wipe inflatable parts with **non acetone** dissolvent (recommended: first make the test in not visible part of the shade).

**Keep away from flame, strong direct heat, sharp edges and rough surfaces.** In case of perforation of the surface – you can fix it with glue for inflatable toys/furniture.

Remember: turn off the electricity before cleaning.

### Conditions of guarantee

We guarantee the perfect condition and function of this appliance. The guarantee is valid for 2 years beginning from the date of sale. We will rectify all faults arising from defective materials or manufacturing. The guarantee covers repair or replacement of the defective parts, subject to our approval. The guarantee does not apply to damage to parts which are subject to wear and tear nor damage or defects caused by improper use or incorrect maintenance. The guarantee only applies if the purchase receipt is sent to the producer together with the appliance.

**Made in Poland**

230 V (European), 110 V (American)

 compact fluorescent, E26 / E27

